



Clean Water Made Easy

Pro-Ox Media Change Guide

Please review this start-up guide entirely before beginning to install your system and follow the steps outlined for best results.

The Pro-OX media must be activated with a 1 cup of un-scented liquid chlorine bleach when first installing it. Read instructions for more information. It is easy to do, but a critical step.

The Pro-OX media contains dust. Use paper mask and ventilate area to avoid breathing dust when first pouring the media into the tank.

**Minimum 30 PSI required. Maximum pressure 90 PSI.
For indoor installation. Protect from sunlight, rain, and freezing.**

Watch These How-to Videos:

https://www.youtube.com/playlist?list=PLIYo0ek4wcmY2tXbX_7zUlKxoEpwz4DyL

For assistance call: 1-831-462-8500 M-F 8AM to 4PM PST

Email us: office@cleanwaterstore.com

More information online: www.cleanwaterstore.com

Remove Old Media

1. Shut off water to filter and open hose bib or faucet downstream to relieve water pressure.
2. If your system has bypass valves, put control on bypass by turning both bypass valves to bypass position.
3. Unplug power cable from control valve.
4. Unscrew control valve by hand
5. Siphon water out of distributor tube and tank if possible.
6. Lay tank down on its side on a large plastic tarp or sheeting.
7. Run a garden hose down distributor tube until water and media start to flow out opening.
8. If possible, lift the bottom base of tank and place on a block so bottom of tank is elevated by 1 or 2 feet higher than top opening of tank.
9. Continue to run garden hose and remove distributor tube
10. Flush out all old media in the tank on to the tarp or plastic sheet.
11. Gather old media, OK to dispose in trash, it is not toxic.
12. Add a ½ cup of bleach and 2 – 3 gallons of water to tank and clean out tank.

Add Filter Media and Re-install Control Valve

1. **Make sure you “test fit” distributor tube, find divot that keeps tube centered, before adding gravel so distributor tube does not extend past top of tank.**
2. There are two styles of funnel that we ship, depending on availability; you get either the blue or black funnel.
3. If blue funnel, cover top of distributor tube with black electrical tape, duct tape or masking tape so no gravel or media will go down distributor tube when adding media.
4. Leave a folded tab of tape so you can easily pull off tape after filling the tank.
5. Hold the tube center until there is enough gravel and media to support the tube. The top of the distributor tube should be level with the top opening of the filter tank.

Make sure top of distributor tube
is level with top of tank



6. Add the filter gravel that came with your order. The gravel should cover the bottom distributor screen before adding the Pro-OX filter media.
7. Next, add the Pro-OX Filter media, then the Turbidex Media (formerly called Chemsorb)
8. The tank should be about 2/3 full of media, do not fill much more than 2/3 full, even if there is media left over. We ship the correct amount of media to fill your tank for most orders.
9. Add 1 cup of household bleach down the distributor tube and fill tank completely with water. Allow to soak for at least 1 hour up to 24 hours before you hook it up to piping.
10. Remove tape from top of distributor tube. Be careful not to pull up distributor tube.
11. Lubricate control valve orings with silicone grease (only). Don't use other lubricants, Teflon tape or joint compound.
12. Install control valve and follow start instructions that came with your system.