



Auto Backwash Neutralizer Filter System





Flow Diagram Not to scale



Plan View



Key

-  Optional Gate or ball valve
-  Optional Pressure gauge
-  Optional Hose bib
-  Water piping

Notes: follow inlet and outlet arrows on filter for proper installation. Connect 1/2" flexible tubing from backwashing control valve to a drain with an air-gap similar to what a washing machine might require, such as 1 1/2" ABS with a p-trap and vent or to other type of drain. Follow all local plumbing and electrical codes.