



Automatic Neutralizer Filtration System Flow Diagram

Plan View:



Elevation View:



Key

	Gate or ball valve	Pressure gauge	Hose bib	Pressure Switch	Water piping
Elevation view					
Plan view					

Notes: follow inlet and outlet arrows on filter for proper installation. Install system using bypass valve. Connect 1/2" flexible tubing from backwashing control valve to a drain with an air-gap similar to what a washing machine might require, such as 1 1/2" ABS with a p-trap and vent. Follow all local plumbing and electrical codes.