



Clean Water Made Easy

www.cleanwaterstore.com

Upflow Carbon Installation & Start-Up Guide

For Up-Flow Carbon filters with Vortech Distributor Screen

Thank you for purchasing a Clean Water System! With proper installation and a little routine maintenance your system will be providing treated water for many years.

CARBON MEDIA CONTAINS DUST. USE PAPER MASK AND VENTILATE TO AVOID BREATHING DUST

Questions?

Call us toll-free: 1-888-600-5426 or 1-831-462-8500

Email us: support@cleanwaterstore.com

See more information on our website: www.cleanwaterstore.com/resources





Clean Water Made Easy

www.cleanwaterstore.com

Table of Contents

PACKING LIST:.....	3
Carbon Upflow 1.5 Cubic Foot:	3
Carbon Upflow, 2.0 Cubic Foot	3
Carbon Upflow 2.5 Cubic Foot:	3
Pre-Installation	4
Best Practices for Piping & Drain Installation.....	4
How Your Carbon Filter UpFlow Works:	5
Figure 1 - Upflow Carbon tank diagram	5
Assembly and Installation Instructions	6
Maintenance	7

PACKING LIST:

Carbon Upflow 1.5 Cubic Foot:

Your new 1.5 Cubic Foot Upflow Carbon filter includes:

1 – 1 cu. Ft. Bag

1 - .5 cu. Ft. Bag

Carbon Upflow, 2.0 Cubic Foot

Your new 2.0 Cubic Foot Upflow Carbon filter includes:

2 – 1 cu. Ft. Bags

Carbon Upflow 2.5 Cubic Foot:

Your new 1.5 Cubic Foot Upflow Carbon filter includes:

1 – 1 cu. Ft. Bag


1 - .5 cu. Ft. Bag

Pre-Installation

1. Review your packing list and make sure you have received all the parts before beginning installation.
2. If you are going to be turning off the water to the house and you have an electric water heater, shut off the power to the water heater before beginning installation in case the water heater is accidentally drained.
3. Pick a suitable location for your filter system on a dry level spot where it won't be exposed to freezing temperatures. A minimum of 20 PSI is required. Maximum pressure is 90 PSI.
4. Get all of your plumbing parts together before beginning installation. Installation typically takes 3 to 5 hours. Once completed and pressure tested you will want to run the water in your home for 15 – 20 minutes to clear out any fines from the new medium.
5. After the system is installed and running, your water may be discolored or full of sediment or rust, particularly if this is older or corroded piping. This typically clears up over a day or two.

Best Practices for Piping & Drain Installation

1. If you are setting up your filter to be an Upflow filter, connect the **IN pipe to the Upflow Inlet** (on the right side when facing the pipe connectors), and then connect the **Out pipe to the Downflow Inlet (diagram below)**. The water should flow down the distributor tube and up through the filter media. The arrows may be facing either direction, so do not rely on the arrows.




2. Make sure there is a working gate or ball valve before the Upflow Carbon filter and also one after. Pressure gauges are optional and perhaps not necessary but a hose bib (which is a faucet that you can attach a garden hose to) is strongly recommended after the neutralizer filter and before the second ball valve. This makes it easy to rinse your new filter on start-up and gives you a place to test the water before it enters your household plumbing.
3. If you will be using copper piping, do not sweat the copper pipe directly on to the filter. Avoid heating the plastic.

How Your Carbon Filter UpFlow Works:

See Fig 1. In your Carbon Filter water enters the top of the tank and flows down through the distributor tube and up through the carbon media.

Figure 1 - Upflow Carbon tank diagram




Assembly and Installation Instructions

1. Unscrew the top fitting on the tank by hand if it was shipped screwed on. Place the distributor tube in the tank if not already inside. If not already done, make sure the blue cap is on top of the distributor tube, or wrap the top of distributor tube with electrical or duct tape. **You do not want any carbon to go down the distributor tube, this is very important!**



2. Next add the carbon media. Disregard the black plug in the tank, that is a dome hole and not included with Carbon systems.
3. Remove cap or tape from the top of the distributor tube. This is a Vortech tank the distributor should be fully installed and not able to be removed from the tank.
4. If possible at this point, fill the tank completely with water. This will allow the carbon media to settle and eliminate the need of “purging” the air out of the tank later.
5. Attach optional plastic top screen to the under-side of the in-out head. It is a funnel-shaped plastic screen that snaps on to the control valve and prevents media from escaping from the carbon filter.
6. Connect the **IN pipe to the Upflow Inlet** (on the right side when facing the pipe connectors), and then connect the **Out pipe to the Downflow Inlet (diagram below)**.



7. With the system on bypass, and the valve after the filter closed, open the hose bib tap after the carbon filter and allow water to run for a couple of minutes to flush out any materials used in the piping.
8. Now take the Carbon filter off bypass. With the valve after the filter closed, allow the up-flow carbon to flush for 10 to 20 minutes through the hose bib. This is necessary to flush out carbon fines and dust. The water will be discolored to be black in color at first.

Maintenance

Make sure to occasionally monitor the chlorine residual after the carbon filter, there should be very little to no chlorine coming out of the carbon filter. After 1 to 3 years (depending on usage), or when you start to detect a chlorine residual in the water after the carbon filter, replace the carbon media with new carbon.

Need Assistance?

Call us at 831-462-8500 or email support@cleanwaterstore.com