



Clean Water Made Easy

www.cleanwaterstore.com

1054 and 1354 Contact Tank Piping Guide

1. Connect the Inlet to the In port on top of the contact tank and Outlet to the Out port (see top of tank, marked Inlet and Outlet).
2. The water flows in and out the top. An internal distributor tube provides mixing and contact time.
3. The bottom drain is for flushing (valve not included)
4. Install a PVC or other ball valve on the bottom of the tank in order to be able to drain down the tank periodically.
5. Every few months, open the valve at bottom and flush the tank under pressure to flush out any accumulated sediment.



Questions?

Call us toll-free: 1-888-600-5426 or 1-831-462-8500

Email us: support@cleanwaterstore.com

See more information on our website: www.cleanwaterstore.com/resources